

Vor dem Zusammensetzen gut durchlesen!

[illegible][illegible]





GR: ATTENTION: Read the instructions thoroughly prior to assembly. Each component is numbered (1). Adhere to specified sequence of assembly. Reels require knife and file for removal of components from frames (2); rubber band, adhesive tape and define page for clamping components together after applying objectives (3). Clean plastic components in a mild detergent solution and allow to air-dry so that paint and transfer adheres better. Prior to applying adhesives, check to see whether the components fit together; apply adhesive sparingly. Remove excess wet glue from the contact surfaces. Fold small components before removing them from the frames (4, 5). Allow paint to dry well, and only then continue to assemble. Cut each card transfer individually and laminate to warm water for covers. 20 seconds, double transfer off paper and seal between slides with Waflexin sealer.









[illegible][illegible]




L'ATTENDONE. Prima dell'assemblaggio bisogna attentamente la taratura di montaggio. Ogni pezzo è numerato (1). Questi possono le sostituzioni insieme i pezzi di sostituzioni. Inoltre il sistema di bloccaggio dei bocconi per ringhiere e i pezzi di sostituzioni (2). L'armatura è in plastica con un designatore di colore e i blocchi di sostituzioni per l'ordine, per una migliore identificazione. La ruota di colore e della figura designa la funzione. In alcuni modelli, nell'area dei pezzi di sostituzioni hanno di loro applicato il colore per distinguere. Tagliare e colare dalle figure specifiche. I modelli di tagliare i pezzi necessari al pezzo di rimontaggio (3). Per assemblare bene la vettura prima di proseguire con l'assemblaggio. Tagliare dagli elementi ogni figura ed innervigile in cinque impilare per 20 secondi (4). Applicare il metallo nella posizione desiderata e temporizzare con carta adesiva.










[illegible][illegible]








GR: ΠΡΟΣΧΩΝ: Πριν τη συσχετισμένη συζήτηση, κατά τις οποίες, κάθε ερώτηση είναι απάντηση, να (1). Προσέξτε τη σειρά των επιτηρητών. Αναμενόμενα ερωτήσεις: ποια και πότε για τη λείανση των ερμητημάτων (2), μετέγινε ταύτα, καθήκοντά ταύτα και μεταλλάξεις για τη συζήτηση της κολλήματων μηχανισμών ερμητημάτων (3). Καθόριστε τα παλαιότερα ερμητικά μέσα σε ένα "backlog" καθολικιστή διάταξη και στένεψτε το στον αέρα, ώστε να υποβάλει καλύτερη πρόβλεψη του χηλίστου και των χηλίστων. Πριν το τελήρημα, ελέγξτε αν υπάρχουν πετάκια τους να ερμητίζονται. Επαμείνεται οικονομικά την κόλλα. Απομεινόμενα από τη σημερινή επιθεώρηση, χρόνο και θέση. Βλέπετε τη μικρή ερμητική, πριν αναμειγνύμενη από τα μέλαινα (4). Αφίστε να στεγνώσουν καλά τα χηλίσματα και να ερμητίζονται στην υπερβολική κόλλα. Κόβετε ξεχωριστά από το ποτήρι των χηλίσμων και ποτίζετε τα σε ζεστό νερό για περί-20 λεπτά. Απομεινόμενα τα ποτήρια από το χηρί, στο σημερινό μέγεθος επιμολύ και πότε τα με τα βουρτσάκια.

[illegible][illegible][illegible]












31 37/39




32




33 10X




34 19/59/60




35




36 2x




37 56/57



39




38 2x




?


40




41




42




43




44




45



46



47



Republic P-47N-1-RE Thunderbolt of
318th Fighter Group, 19th Fighter Squadron at Ie Shima, Japan;
May 1945






















Figure 1


FAR-Rockets
- Both Sides -






- All Version -
Wing Tanks
- Left Side -






49





Republic P-47N-2 Thunderbolt of
73rd Fighter Squadron, 318th Fighter Group
Ie Shima, Japan; May 1945



FAR-Rockets
- Both Sides -



Wing Tanks
- Left Side -



Wing Tanks
- Right Side -

